

Firmware Upgrading Procedures

1. Download and save the latest firmware available from "Download Center" in www.true-i.com to user defined folder or an SD card.

2. Unzip the downloaded file to uncompress.
User will see the files named "hmbs200.bin" and "setup.hms" as successful unzip of the downloaded file.

3. Copy and paste the files into SD card if user saved the files in a PC or other storage device.

4. Remove the power supply cable from device and make sure that the device power is completely turned off.

5. Insert the updated SD card.

6. Connect back the power supply cable to device

7. ORANGE LED will be turned on and the device will start upgrading the firmware automatically.

8. Updating the firmware may take more than 1 minute and wait until system reboots the device and RED LED will be turned on permanently.

**** DO NOT TURN OFF THE POWER AND DO NOT PRESS ANY BUTTONS WHILE FIRMWARE UPDATING IS IN PROGRESS.**

9. If firmware is updated successfully to the device, the "hmbs200.bin" file will be automatically deleted from SD card and device will create "BLACKBOX" and "MOVIE" folders.